

Available in TunerStudio 2.3+ and Shadow Dash 1.16+


Want to start logging when you foot goes down to capture every wide open trip?

May you want to stop logging when the engine shuts down, now you can set this up with basic simple triggers or if you aren advanced user you can make the conditions as complex as your heart desires.

Set any conditions to start and stop data logging.

Automatic Logging:

The automatic logging feature allows you to set up logging to automatically start and stop when conditions you define occur.



Auto Logger Setup :

To set up the auto log feature go to the "Data Logging" drop down menu and click on "Automatic Logging" . Once the automatic logging dialog is open you will

need to click on the Enable box at the upper left hand corner .

You can set up the auto logging feature many different ways.


The simple method has a drop down menu with a very long list of optional engine parameters to choose from . Once you have picked which engine parameter you would like to trigger your data logging you can then pick from a list of three options .

"Engine Parameter" > greater than your entered value .

"Engine Parameter" = equal to your entered value .

"Engine Parameter" < less than your entered value .

If you want to make a custom condition that will turn your logging on or off then you can select the "Expression" option and enter an equation .



The image shows a dialog box titled "Automatic Logging" with a close button (X) in the top right corner. The dialog is divided into two main sections: "Automatic Logging Trigger" and "Stop Logging When".

Automatic Logging Trigger

- Enabled
- Start Logging When**
 - Manual
 - Simple: [] > []
 - Expression: rpm > 2500 && tps > 50
- Stop Logging When**
 - Manual
 - Simple: rpm < 100
 - Expression: []

At the bottom right of the dialog are two buttons: "Accept" and "Cancel".

Example of how to start logging with a trigger RPM > 2500 && TPS > 50